



Owners Manual

# INFLATOR 3500

12 Volt Air Inflator



PART #: i3500

---

This Manual contains information regarding the safety and operation of this product. Before you use, read and understand all instructions, cautions, and warnings. Failure to do so can result in serious injury or property damage.

## Table of Contents

### Page No.

General Safety Rules .....	3
Safety Symbols, Words and Labels .....	3
Specifications .....	4
Important Safety Information .....	4
Parts Diagram .....	5
Operating Instructions .....	5
Warranty information .....	6

### LIMITED ONE YEAR WARRANTY POLICY

Every product is thoroughly inspected and tested before leaving the factory. It is warranted to be free of defects from workmanship and materials for the period of ONE YEAR from date of original purchase. Should any trouble develop during this one year period, please contact our Customer Service Center at 1-800-874-5771 between 800 a.m. and 5:00 p.m. Mountain Standard Time, Monday through Friday. **This warranty does not apply to the following: Where repairs have been made or attempted by others; where repairs are required because of normal wear and tear; if the product has been abused, misused, or improperly maintained; any alterations have been made to the product. IN NO EVENT SHALL BON-AIRE INDUSTRIES, INC. BE LIABLE FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES FROM THE SALE OR USE OF THE PRODUCT. THIS DISCLAIMER APPLIES BOTH DURING AND AFTER THE TERM OF THIS WARRANTY.** This warranty gives you specific legal rights, and you may also have other rights which vary from state to state in the United States. Some states do not allow the exclusion or limitation of incidental or consequential damages, and/or some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

Manufactured for Goodyear by:

**BON-AIRE®**

873 E. Citation Court

Boise, Idaho 83716 USA

800-874-5771

ba@bon-aireindustries.com

GOODYEAR (and winged foot design) is a trademark of The Goodyear Tire & Rubber Company, Akron, Ohio USA used under license by Bon-Aire Industries, Inc.

## SPECIFICATIONS

**THIS INFLATOR OPERATES ONLY ON 12 VOLT DC OR THE INTERNAL BATTERY. DO NOT ATTEMPT TO OPERATE THIS INFLATOR WITH ANY OTHER SOURCE OR VOLTAGE. DO NOT REWIRE OR RECONFIGURE INFLATOR FROM ITS ORIGINAL DESIGN OR PERSONAL INJURY OR BODILY HARM MAY OCCUR.**

<b>Voltage</b>	12 V
<b>Power Requirement</b>	DC 12V/12A – For use with 12 Volt DC Power Outlet Only

**Note:** This unit is equipped with fuse protection. If at some point your Inflator fails to operate, check the fuse in the end of the 12 volt plug. To replace the fuse, simply unscrew the 12 Volt power plug tip, install new fuse and reassemble power plug tip. Use only an AGC - 15 amp replacement fuse.

## IMPORTANT SAFETY INFORMATION



### WARNING

- Use 12 volt DC only. Make sure that your vehicle 12 Volt power outlet is free of any ash residue or debris. A dirty 12 Volt power outlet can cause the inflator and power cord to overheat. Overheating can cause damage to your inflator/vehicle and could cause bodily harm or injury (Disconnect power when not in use).
- This inflator is designed to inflate car tires, bike tires, ATV tires, sports equipment, air mattresses, beach toys and other inflatables. Do not use for any purpose other than inflating. If you do so, bodily harm or personal injury can occur.
- When operating your inflator do not run more than 10 minutes continuous use. Allow inflator to cool down 10 minutes before re-using.
- After using, turn off power.
- The inflator is not a toy. Keep away from children at all times.
- Do not carry inflator by the air hose or power cord or damage may occur.
- Do not leave the inflator unattended while in operation.
- Do not over-inflate. Please follow the manufacturer's instructions for the item you are inflating
- Keep the inflator away from flammable areas/liquids at all times.
- Do not operate inflator in wet or damp areas.
- Operate inflator only with the accessories that are included.
- USE SAFETY GLASSES. Also use face or dust mask if operation is dusty.

## PARTS DIAGRAM



- | Item # | Name                                    |
|--------|---|
| 1      | 12 Volt Plug                            |
| 2      | Pressure Gauge                          |
| 3      | Power On/Off Switch                     |
| 4      | Removable Flashlight                    |
| 5      | Valve/Tire Chuck                        |
| 6      | Rubber Raft/Air Mattress Adapter Nozzle |
| 7      | Ball Adapter Nozzle                     |

## OPERATING INSTRUCTIONS

### To inflate vehicle tires:

- Connect the 12 volt plug (1) into 12 V power outlet (cigarette lighter).
- Connect the Valve/Tire chuck (5) to tire's air stem valve and push down the Valve Lock Lever (5) to secure the connection.
- Slide the On/Off switch to "On" position and the inflator will begin to operate. Inflate your tire or desired item to the correct pressure and shut off the inflator by sliding the On/Off switch to the "off" position.



### CAUTION

**DO NOT OVER-INFLATE YOUR ITEM**

## Use Adapter Nozzles to inflate sports balls, air mattresses, rubber rafts, etc.:

Your Inflator comes with 2 adaptor nozzles: a raft inflator nozzle (6) and a sports ball nozzle (7). Select desired nozzle and follow the same procedure for inflating tires.



**CAUTION**

**DO NOT OVER-INFLATE YOUR ITEM**

## To Remove Flashlight (optional for operation):

**Note:** Four (4) AAA batteries needed to operate flashlight when removed from Inflator.

Remove flashlight (4) from Inflator by grasping the flashlight release buttons located on the side of the flashlight, Squeeze the release buttons and lift upward.

**To Operate Flashlight.** Slide the flashlight On/Off switch to "On" position and the flashlight will shine. Turn off by sliding the On/Off switch to the "Off" position.




### **WARNING:**

DO NOT DISPOSE OF BATTERY IN FIRE AS IT MAY EXPLODE.

REPLACE ONLY WITH SAME OR EQUIVILANT BATTERY TYPE.

### Installing AAA batteries into light



② Insert 4 AAA batteries placing negative end of battery touching the spring.

① Press down on battery compartment door while sliding door down.

**Please remove batteries for long-term storage.**

## GENERAL SAFETY RULES



### **WARNING**

Read and understand all instructions. Failure to follow instructions can result in electric shock, fire and/or serious personal injury. **SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

## SAFETY SYMBOLS, WORDS AND LABELS

The safety instructions provided in this manual are not intended to cover all possible conditions that may occur during product operation. Always use common sense and pay attention to all **WARNING** and **CAUTION** statements in this manual.



### **WARNING**

**WARNING** indicates a potentially hazardous situation. Failure to avoid may result in serious injury or death.



### **CAUTION**

**CAUTION** indicates a potentially hazardous situation. Failure to avoid may result in minor personal injury.

## INTENDED USE

This product is intended for consumer use only.